

Auto Configuration Process to Acquire 72.5° and 95° By Receiver Model

If you need to run an auto configuration on a DIRECTV Receiver, find the receiver model number below and follow the steps outlined.

1. DIRECTV D10

- Press “MENU” on the remote
- Select “SETTINGS”
- Select “SATELLITE”
- Select “AUTO DETECT”
- Press (dash) on the remote three times

2. DIRECTV D10-200

- Press “MENU” on the remote
- Select “SETUP”
- Select “INSTALLATION”
- Select “SET DISH”
- Select “AUTO DETECTION”
- Select “SELECT”

3. DIRECTV D10-300

- Press “MENU” on the remote
- Select “SETUP”
- Select “DISH TYPE”
- Select “AUTO SELECTION”
- Select “START AUTO SELECTION”

4. DIRECTV HR10-250

- Press “DIRECTV” on the remote
- Select “READ NEW MESSAGES & SETUP”
- Select “SETTINGS”
- Select “SATELLITE & OFF AIR ANTENNA”
- Select “RESET SATELLITE INFORMATION”
- Press “Thumbs Down” three times
- Press “ENTER”
- Follow the remaining on-screen instructions to finish auto configuration process

5. HNS HBH-SA, HAH-SA, SD-HBH

- Press “MENU” on the remote
- Select “SYSTEM SETUP”
- Highlight “INSTALL” and scroll right
- Select “AUTO CONFIG”

6. HNS HTL-HD, Sony SAT-HD300, Zenith LSS-3200A

- Press “MENU” on the remote
- Select “SYSTEM SETUP”
- Highlight “INSTALL” and scroll right
- Select “AUTO CONFIG”

7. Philips 5500/5400

- Press “MENU” on the remote
- Highlight “SETUP” and press “OK”
- Highlight “DISH TYPE” and press OK
- Highlight “AUTO SELECTION” and press “OK”
- Press OK to start auto selection, wait for all 19 steps to complete

8. RCA 435RH, 455RH, 486RH

- Press “MENU” on the remote
- Select “SYSTEM SETUP”
- Select “RECEIVER OPTIONS”
- Select “MULTISWITCH SETUP”
- Select “CONTINUE”
- Select “AUTO DETECT”
- Select “CONTINUE”

9. RCA DTC-210

- Press “MENU” on the remote
- Select “SYSTEM SETUP”
- Select “INSTALLATION”
- Select “SET DISH”
- Select “AUTO DETECTION”
- Select “OK”

10. Samsung SIR-S300W, SIR-S310W, SIR-S360W

- Press “MENU” on the remote
- Select “SETUP”
- Select “INSTALLATION”
- Select “SET DISH”
- Select “AUTO DETECTION”
- Select “OK” or “SELECT”

11. Sony SAT-HD200, Zenith HD-SAT520

- Press “MENU” on the remote
- Select “DIRECTV”
- Select “INITIAL SETUP”
- Select “SELECT DISH”
- Select “AUTO DETECTION”

12. DVR Receivers: HNS HDVR2, SD-DVR120, SD-DVR40, SD-DVR80; Philips DSR7000/17, DSR704, DSR708; RCA DVR120, DVR39, DVR40, DVR80; Samsung SIR-S4040R, SIR-S4080R, SIR-S4120R

- Press “DIRECTV” on the remote to get to DIRECTV Central
- Select “MESSAGES & SETUP”
- Select “RECORDER & PHONE SETUP”
- Select “AUTO DETECT SATELLITE INFORMATION”
- Press “Thumbs Down” 3 times
- Press “Enter”
- Follow the remaining on-screen instructions to finish the process