

# Contents

---

<b>Safety</b> .....	<b>v</b>
<b>Introduction</b> .....	<b>1</b>
Welcome to DISH Network .....	1
Overview .....	1
If You Need More Assistance .....	2
Quick Start Guide .....	2
About Satellite Television .....	3
Satellite Signal Quality .....	3
<b>Parts of the System</b> .....	<b>5</b>
The Receiver Front Panel .....	5
The Receiver Back Panel .....	6
The Remote Control .....	7
The Menus .....	11
The Browse Banner .....	15
<b>Using the System</b> .....	<b>17</b>
Changing Channels .....	17
Using the Menus .....	17
Using the Program Guide .....	20
Using the Program Banner .....	22
Using the Browse Banner .....	22
Ordering Pay Per View Programs .....	24
Using Themes .....	25
Using Search .....	25
Using Favorites Lists .....	27
Using Timers .....	29
Using Locks .....	36
Using Caller ID .....	44
Restarting the Receiver .....	46
Resetting the Receiver to Factory Settings .....	46
Changing Program Languages .....	46
Testing the Phone Connection .....	47
Setting Up the Receiver for Channel 3 or 4 .....	48
<b>Installation Instructions</b> .....	<b>49</b>
How to Use these Instructions .....	49
Connecting Your TV and VCR .....	49
Installing a DISH 500 Antenna .....	50
DishPro Wiring Diagrams .....	60
Running Coaxial Cable .....	67
Connecting the Receiver to a Phone Line .....	68

**Reference..... 71**  
    Troubleshooting Tables ..... 71  
    Device Codes ..... 81

**Appendix A ..... 83**

**Appendix B ..... 85**  
    Limited Warranty ..... 85  
    Residential Customer Agreement ..... 88  
    Staying Legal ..... 94  
    FCC Compliance ..... 94

**Index..... 97**